



UNTIL 2024



POS.	CODE	DESCRIPTION	QTY
4	A00512	SWITCH	1
5	A00513	SWITCH COVER	1
6	A00514	VACUUM ADAPTER	1
7	A00591	SINGLE ROW BALL BEARING 606 RS	1
8	A00516	FIELD	1
9	A00411	POWER CORD 2x0,75mm H05RN-F WITH BLACK PLUG, 4m	1
13	A00379	POWER CORD GUARD	1
14	A00386	POWER CORD CLIP	1
19	A00524	CAPACITOR 275V 0,22µF 19x14x6mm WITH WIRING	1
22	A00527	AIR GUIDE	1
23	A00528	BRACKET	1
28	A00533	ARMATURE	1
29	A00485	SINGLE ROW BALL BEARING 608 RS	1
30	A00535	COUNTERWEIGHT	1
31	A00492	SINGLE ROW BALL BEARING 628 RS	1
32	A00536	BRACKET	1
33	A00537	ANTIVIBRATION MOUNT	1
SET 1	A00511	LEFT & RIGHT HOUSINGS	1
SET 2	A12211	CARBON BRUSH & HOLDER	2
SET 3	A13107 Until 2024	UPPER & LOWER BASE PAD	1
SET 4	A13934 Until 2024	BASE PLATE & UPPER & LOWER BASE PAD	1

SINCE 2025



POS.	CODE	DESCRIPTION	QTY
4	A00512	SWITCH	1
5	A00513	SWITCH COVER	1
6	A00514	VACUUM ADAPTER	1
7	A00591	SINGLE ROW BALL BEARING 606 RS	1
8	A00516	FIELD	1
9	A00411	POWER CORD 2x0,75mm H05RN-F WITH BLACK PLUG, 4m	1
13	A00379	POWER CORD GUARD	1
14	A00386	POWER CORD CLIP	1
19	A00524	CAPACITOR 275V 0,22μF 19x14x6mm WITH WIRING	1
22	A00527	AIR GUIDE	1
23	A00528	BRACKET	1
28	A00533	ARMATURE	1
29	A00485	SINGLE ROW BALL BEARING 608 RS	1
30	A00535	COUNTERWEIGHT	1
31	A00492	SINGLE ROW BALL BEARING 628 RS	1
32	A00536	BRACKET	1
SET 1	A00511	LEFT & RIGHT HOUSINGS	1
SET 2	A12211	CARBON BRUSH & HOLDER	2
SET 5 Since 2025	A13933	BASE PLATE & BASE PAD	1